

## **Crown & Drive for Somfy Motors**

MOTOR TUBE	500 AC/DC	ST40 & ST40 WF	ST30 WF & ST30 24VDC	ST30	R28
<b>RS-T36</b> 1 1/4" Z-Tube					Crown: 9018474 Drive: 9018476
RS-T46 1 1/2" Z-Tube			Crown & Drive: 9020674 or RS-B82	Crown & Drive: 9013775	Crown: 9018475 Drive: 9018477
RS-2TU 1 1/2" RS-Tube			Crown & Drive: 9020675 or RS-B81	Crown & Drive: 9013775 or 9014045 (including plate)	Crown: 9018588 Drive: 9018598 (including plate)
<b>RS-032</b> 1 1/2" Groove tube		Crown: RS-B73 Drive: RS-B59	Crown: 9020676 & RS-B73 Drive: RS-B59	Adaptor: 9013776 Crown: RS-B73 Drive: RS-B59	Adaptor:9013776 Crown:9018588 Drive:RS-B59
RS-3TU 1 3/4" RS-Tube				Crown & Drive: 9014333 (including plate)	Crown: RS-B74 Drive: 9014333(including plate)
<b>RS-T56</b> 2" Z-Tube	Samfu product. Alabanya ari a part	Crown & Drive: RS-977 or 9016352	Crown & Drive: 9021017 or RS-973	Adaptor: 9013776 Crown & Drive: RS-977	

Numerical part No(e.g. 9013775--Somfy product Alphanumeric part No(e.g. RS-B73)--ZMC product







## **Crown & Drive for Somfy Motors**

500 AC/DC	ST40 & ST40 WF	ST30 WF & ST30 24VDC	ST30	R28
			0,000	
	-	1 · · · · · · · · · · · · · · · · · · ·		
Drive: RS-981 or RS-B47	Drive: RS-981 or RS-B47	Drive: RS-981 or RS-B47	Drive: RS-981 or RS-B47	
Crown: No need Drive: 9206089(soft clip) or				
920008 (nard clip)				
	Adaptor:9013763 Crown: RS-975 Drive: RS-192 or RS-983	Adapator: 9020676 & 9013763 Crown: RS-975 Drive: RS-192 or RS-983	Adapator: 9013776 & 9013763 Crown: RS-975 Drive: RS-192 or RS-983	
	_			
	Adaptor: 9013763 Crown: RS-984 Drive: RS-982	Adaptor: 9020676 & 9013763 Crown: RS-984 Drive: RS-982	Adaptor: 9013776 & 9013763 Crown: RS-984 Drive: RS-982	
5110c1 110 502	C. C. M. 1. 10 304 D. M. C. 1. 10 302	Crowning your Britering yez	Crowning 364 Britering 362	
		Crown & Drive: 9020675 or RS-B81	Crown & Drive: 9013775 or 9014045 (including plate)	Crown: 9018588 Drive: 9018598 (including plate)
	/		- ( 0,)	( · · · · · · · · · · · · · · · · · · ·
		Crown: 9020675 & ST-2X8	Crown: RS-B77	Crown: RS-B75
		Drive: RS-B76	Drive: RS-B76	Drive: RS-B76
	Crown: no need Drive: RS-981 or RS-B47  Crown: No need Drive: 9206089(soft clip) or 9206088(hard clip)  Crown: RS-975 Drive: RS-192 or RS-983  Crown: RS-984	Crown: no need Drive: RS-981 or RS-B47  Crown: No need Drive: 9206089(soft clip) or 9206088(hard clip)  Crown: RS-975 Drive: RS-192 or RS-983  Crown: RS-975 Drive: RS-192 or RS-983  Crown: RS-975 Drive: RS-192 or RS-983	Crown: No need Drive: RS-981 or RS-B47  Crown: No need Drive: RS-981 or RS-B47  Crown: RS-975 Drive: RS-192 or RS-983  Crown: RS-984 Drive: RS-984 Drive: RS-984 Drive: RS-984 Drive: RS-982  Crown: RS-982  Crown: RS-984 Drive: RS-984 Drive: RS-984 Drive: RS-984 Drive: RS-985 Drive: RS-984 Drive: RS-984 Drive: RS-984 Drive: RS-985 Drive: RS-985 Drive: RS-985 Drive: RS-985 Drive: RS-9865 Drive: RS-9866 Drive: RS-9866 Drive: RS-9875 Drive: R	Crown: no need Drive: RS-981 or RS-847  Crown: RS-975 Drive: RS-975 Drive: RS-192 or RS-983  Crown: RS-984 Drive: RS-985 Drive: RS-984 Drive: RS-985 Drive: RS-984 Drive: RS-985 Drive: RS

Numerical part No(e.g. 9013775--Somfy product Alphanumeric part No(e.g. RS-B73)--ZMC product



